Launch Controller V1.0—Setup Software Flow Diagram


```
                    Launch Control
                          |
                        3 Sec
                          |
                   Enter Security
                        Pin:
                     /         \
                   Yes          No
                    |            |
                 Welcome <----   |
                    |        |    |
                  3 Sec      |    |
                    |        |    |
             Wireless Launch |    |
               Single Core   |    |
                /        \    |    |
               #          *---     3 Sec
               |                    |
        Enter Security              |
             Pin:                   |
           /       \                |
         Yes        No --- Access Denied!
          |
    Ready to Launch
          |
       Launch!
          |
    Begin Sequence


        Impossible Task
              |
            Error!
```